

Directions for installation 08 Tundra Rear

Included hardware: 5 \hat{o} Stainless Steel (SS) screws; 5 \hat{o} SS Washers

These instructions are designed to assist with installation on different truck models. The exact location of factory bolts and flat clips may vary for your model.

NOTE: As you progress with the install, check that the mudflap remains square and plumb to the tire.

Step 1: Un-package your new mudflaps. Smooth side is rear side, tapered corner on top is outside top edge. If applicable, Stainless Steel weights face rearwards.

Step 2: Remove factory screws located at points A-E.

Note: Do not remove the push pins.

The mudflap is pre-drilled with holes to fit over those pins at points F and G.

Step 3: Align the pre-drilled hole A in the mudflap with factory hole A and thread the stainless steel (SS) screw thru the SS washer and mudflap and into the factory hole. Leave slightly loose.

Step 4: Repeat step 3 at points B,C,D and E.

Step 7: Check alignment and tighten all screws .

Note: Recheck every three months and retighten if necessary.

