



DURAFLAP INSTALL DIRECTIONS FOR DODGE FRONT 1994-2002

Supplied Hardware: 8 - Stainless Steel Black Oxide (SSBO) self tapping screws; 8-SSBO washers; 2- 1/4-20x1 SSBO bolts; 2- (SS) nyloks;

Tools needed: Drill with 1/8" and 5/16" bit and 3/8" nut driver, small level and locking pliers

Step 1. **PARK VEHICLE ON LEVEL GROUND.**

Step 2. Unpack your Mudflaps and the enclosed hardware.

Step 3. Position the mudflap to the wheel well of choice, with the vertical rain grooves toward the tire, and the tapered corner to the top outside edge. Secure it with a clamp.
Note: On rear mudflaps check for clearance of at least 3" between your tailpipe and the mudflap to prevent damage to the mudflap. It may be necessary to have your tailpipe repositioned by your local muffler shop.

Step 4. Align the mudflap to the desired height, with a minimum of 7 inches from the ground to the bottom of the mudflap. Center the mud flap to the tire. Keep the mudflap perpendicular to the ground.

Step 5. Drill one 1/8" hole through the mudflap and wheel well lip at the upper outside corner and attach with one self-tapping screw thru the washer, mudflap and into the fender lip. Snug the screw, but do not tighten it.

Step 6. Line the mud flap up to be plumb to the tire.

Step 7. Drill a second hole in the bottom outside edge of the mudflap and wheel well lip and secure with a second screw or bolt. If using a bolt, the pre-drilled hole will need to be 5/16".

Step 8. Install the remaining screws evenly spaced and tighten all screws/bolts.

Note: Recheck bolts every three months and retighten as necessary.

IF YOU HAVE ANY QUESTIONS OR CONCERNS PLEASE GIVE US A CALL AT 541-541245-9148

