

Universal Long John Mud Flap Installation Front and Rear

Included Hardware:

(Long John)

- (12) 10 x 1 1/4" self-tapping screws (SSBO)
- (12) #10 (SSBO) washers

Tools Needed:

- | | | |
|----------------------------|--------------------|------------------------------|
| • clamps | • ratchet & wrench | • 3/8 socket on drill |
| • drill | • 1/8" drill bit | attachment for self-drilling |
| • 1/16" or 3/32" drill bit | | screws |

Installation Steps:

1. PARK VEHICLE ON LEVEL WORK AREA.
2. Unpack and verify all parts are included per list above. **If anything is missing, please call DuraFlap at the number below.**
3. Position the mud flap with the grooved side toward the tire and the tapered corner to the top outside edge.
 - a. Line up the mud flap to be centered on the tire when viewing from rear.
 - b. Adjust height. **DuraFlap recommends 7 to 9" off the ground.**
 - c. Temporarily clamp the mud flap in place.
4. Double check mud flap is square and plumb to the tires.
5. Drill the first hole (1/16 or 3/32) through the mud flap and into the wheel well lip at the lower outside corner.
 - a. Secure with the self-tapping screw thru the washer, mud flap and into the fender lip. Leave slightly loose for now.
6. Recheck mud flap, ensuring it is centered and plumb.
7. Drill the second hole in the bottom outside edge of the mud flap and wheel well lip and secure with a second screw and washer.
8. Repeat with remaining screws. Tighten all screws. **Screws should be evenly spaced when finished.**



WARNING: On rear mud flaps check for clearance of at least 3" between your tailpipe and the mud flap to prevent damage to the mud flap. It may be necessary to have your tailpipe repositioned by your local muffler shop.

NOTE: Check bolts and screws for tightness every three months.
Replace moisture in the mud flap by applying furniture polish, vinyl or leather treatment or other moisturizer twice a year.

If you have any questions, give us a call. (541) 245-9148