



2021-Current Ram 1500 TRX Rear Installation Instructions

Supplied Hardware:

6- SSBO #10 x 1.25 Screws 6- SSBO #10 washers;

Thread Locker is recommended on all screws.

NOTE: *As you progress with the install, check that the mud flap remains square and plumb to the tire.*

Step 1: Un-package your new mud flaps. Smooth side is rear side, tapered corner on top is outside top edge with rain grooves facing tire side. If applicable, Stainless Steel weights face rearwards.

Step 2: Remove the factory screws located at points (A), (B), (C), and (D).

Step 3: Place the mud flap in the fender well line up the holes and secure it with the #10 Screws with washers.

Step 4: Recheck alignment and tighten all screws and bolts.

NOTE: Recheck every three months and retighten all bolts and screws as needed.

Apply moisture such as furniture polish or vinyl treatment twice a year.

IF YOU HAVE ANY QUESTIONS OR CONCERNS PLEASE GIVE US A CALL AT 541-245-9148



DR12 21 1500 TRX, DR14 21 1500 TRX