



Chevy Colorado 2023-Current Front Install Directions

Included hardware: 4- (#8) x 1.25" screws stainless-steel black oxide (SSBO); 2- (#8) x 1.5" SSBO screws; 6- (#10) SSBO washers; 2 - small u-clips just in case;

2- Flat Clips #10016; 2- 3/4" round plastic spacers #

Thread locker is recommended on all non-nylok fasteners

NOTE: Park on level surface for installation. As you progress with the install, check that the mud flap remains square and plumb to the tire.

Step 1: Remove mud flaps from package. Smooth side faces rear, tapered corner on top is outside top edge. If applicable, Stainless Steel weights face rear.

Step 2: Attach the flat clip to the back (smooth) side of the mudflap at Point A. Use a #8 x 1.25 (SSBO) screw thru the (SSBO) #10 washer, thru the tire side of the mudflap (side with grooves), into the U-clip. Leave loose for now. See picture on the back.

Step 3: Remove the factory screws at points B and C, being careful not to break the u-clip behind the liner.

Step 4: Align the pre-drilled hole in the mud flap with factory hole C and use the (#8) x 1.5" screw and with (#10) washer through the mud flap, then the round plastic spacer and into the u-clip at point C. Leave slightly loose.

Step 5: Secure point B with a #8 x 1.25 screw and washer. Leave slightly loose.

Step 6: Slide the "FLAT CLIP" under the fender well lip, and tighten causing to grip the fender firmly at Pont A.

Step 7: Check alignment and tighten all screws and bolts.

Note: Re-check every three months and retighten if necessary.

Add moisture to the mud flaps 2 times a year. Use furniture polish or vinyl treatment.

IF YOU HAVE ANY QUESTIONS OR CONCERNS PLEASE GIVE US A CALL AT 541-245-9148



