
Included Hardware:
(8-Bolt)

- | | |
|--|------------------------------|
| • (8) 1/4" x 1 1/4" (SS) Self drill screws | • (2) 1/4-20 nylock nuts |
| • (8) 1/4" (SS) washers | • (2) 1/4-20 x 1" bolts (SS) |

Tools Needed:

- | | | |
|------------------|-------------------|------------------------------|
| • drill | • Small level | • 3/8 socket on drill |
| • 1/8" drill bit | • 5/16" drill bit | attachment for self-drilling |
| • locking pliers | • clamps | screws. |

Installation Steps:

1. PARK VEHICLE ON LEVEL WORK AREA.
 2. Unpack and verify all parts are included per list above. **If anything is missing, please call DuraFlap at the number below.**
 3. Position the mud flap with the grooved side toward the tire. Secure it with a clamp.
 - a. Line up the mud flap centered on the tire.
 - b. Adjust height. **DuraFlap recommends 7 to 9" off the ground.**
- Note:** On rear mud flaps, ensure clearance of at least 3" between your tailpipe and the mud flap.
4. Double check mud flap is square and plumb to the tires.
 5. Drill one 1/8" hole through the mud flap and wheel well lip at the upper outside corner.
 - a. Secure it with a self-tapping screw thru the washer, mud flap and into the fender lip. Leave slightly loose for now.
 6. Place the level to the outside edge of the mud flap and adjust for vertical plumb.
 7. Drill the second hole in the bottom outside edge of the mud flap and wheel well lip and secure with a second screw or bolt. If using a bolt, the pre-drilled hole will need to be 5/16".
 8. Install the remaining screws or bolts, evenly spaced and tighten all screw/bolts.



NOTE: Check bolts and screws for tightness every three months.

Replace moisture in the mud flap by applying furniture polish, vinyl or leather treatment or other moisturizer twice a year.

If you have any questions, give us a call. (541) 245-9148