

Included Hardware:

(Trailer)

- (6) 1/4-20 x 1" (SS) stainless steel bolts
- (12) 1/4" (SS) washers
- (6) 1/4-20 nylock nuts
- (6) self-drilling 14 x 1 1/4" screws

Tools Needed:

- clamps
- drill
- 9/32" drill bit (for 1/4-20 bolts)
- 7/16 socket
- ratchet & wrench
- 1/8" drill bit
- 3/8 socket on drill attachment for self-drilling screws.

Installation Steps:

1. PARK VEHICLE ON LEVEL WORK AREA.
2. Unpack and verify all parts are included per list above. **If anything is missing, please call DuraFlap at the number below.**
3. Determine area to hang the mud flap from. Many trailers have cross beams that work well for this purpose. **The best placement is as close to the tires as possible, without contacting the tire.**
 - a. If a storage area exists behind the tire, the mud flap may be able to be attached to that area. Use silicone to seal up any potential leaks from drilling and installing bolts or screws.
4. Position the mud flap with the grooved side toward the tire.
 - a. Line up the mud flap centered on the tire.
 - b. Adjust height. **DuraFlap recommends 5 to 9" off the ground.**
 - c. Temporarily clamp the mud flap in place.
5. Double check mud flap is square and plumb to the tires.
6. Drill the first hole through the top of the mud flap and into the mounting location.
 - a. Secure it with a 1/4-20 x 1 bolt, washer and nut. Leave slightly loose for now.
 - b. **Optionally:** Pre-drill 1/8" holes and attach with self-drilling screws.
7. Recheck mud flap, ensuring it is centered and plumb.
 - a. Drill the second and third holes and secure with bolts/screws. **Bolts should be evenly spaced when finished.**

NOTE: Check bolts and screws for tightness every three months.

Replace moisture in the mud flap by applying furniture polish, vinyl or leather treatment or other moisturizer twice a year.

If you have any questions, give us a call. (541) 245-9148

